

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		




Fig. 1
(Prior Art)

09318668 05599
55250" 89987260




Fig. 3




Fig. 2

55250" 89987E60




Fig. 4

155250" 89987E60




Fig. 5




Fig. 20

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		

665250" 89987E60




Fig.6




Fig. 7

665250" 89987E60




Fig. 8

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		




Fig. 10

565250" 89987E60




Fig. 11

665250" 39987E60




Fig. 12




Fig. 13

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		

65250-8987E60




Fig.14

MBA3000 Multiple Base Adapter




Fig. 15

665250" 89987E60




Fig.16




Fig. 17

65250" 29987E60




Fig.18

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		

665250" 39987E50




Fig.18A

65250" 898TE60




Fig.19

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		

665250-3987E60




Fig.21




Fig. 22




Fig. 23




Fig. 24




Fig. 25

00218666-052590




Fig. 26




Fig. 27

0931660" 89937E60





Fig.28

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		



* The user of the terminal initiates a transmission by pressing the 'ENTER' or, depending on the specific software version, any of the function keys. Pressing these keys causes the terminal to power up the radio and send any data entered by the user.

Fig.29

09318668-052590
065250 " 8998TE60




Fig.30